



White Vinyl Letter Window Decal Application Instructions

Please read instructions completely before starting the application process for starting.

1. Clean the window you are applying the decal to with glass cleaner.
2. Mix 2 drops of liquid soap into spray bottle of water.
3. Place decal on the window you would like it transferred to. You should be able to read the decal correctly.
4. Place a strip of tape across the top of the decal, so the decal is held in place during the application. Be sure to check the decal to make sure it is straight.
5. Remove wax type backing, ensuring letters do not stick to the wax backing.
6. Spray the window and back of decal with water mix. (This is done so air bubbles will work out when decal is applied).
7. Lay decal down using a squeegee. Start at the top, removing any air bubbles as you work your way to the bottom. (If squeegee is not available a rag will do).
8. Once you have rubbed over the decal and worked out any air bubbles, peel the piece of tape off the top.
9. Now peel off remaining tape making sure decal sticks to the window you are applying it to.
10. Pat dry with rag, working out all the air bubbles that are remaining.
11. Do not rub or use wipers for 24 hours to let decal completely dry and adhere to window.

If you have any questions or concerns, please call MKConnections at 1.800.627.9577